

LEAD SCREENING KIT



CODE 5-0140

QUANTITY	CONTENTS	CODE
10	Lead Screening Kit Foil Pouches	80030

WARNING! Not to be used by children except under adult supervision.


PROCEDURE



1. Open foil pouch. Using dropper, place exactly TWO droppers full of water sample into small test vial included in the pouch. To pick up sample, tightly squeeze the bulb at the end of the dropper and place the open end into water sample. Release the bulb to pick up sample, then squeeze again to expel sample into vial.




2. Swirl vial gently for several seconds. Place on a flat surface.



3. Place Lead Test Strip (8003) in the test vial with arrows pointing DOWN.



4. Wait 10 minutes. Do not disturb the strip or vial during this time. Blue lines will appear on the strips.




5. Take the strip out of the vial and lay it on a flat surface with the arrows pointing to the LEFT. Read result.




RESULTS

NEGATIVE RESULT (less than 15 ppb): LEFT line, next to number 1, is darker than the RIGHT line, next to number 2 OR if you only see one line the result is negative.



POSITIVE RESULT (greater than 15 ppb): RIGHT line, next to number 2, is darker than the LEFT line, next to number 1, OR if both LEFT and RIGHT lines are equally dark the result is positive.



Note: If no lines appear, or both lines are very light, the test did not run properly and the result is not valid. Read SDS at www.lamotte.com

LaMOTTE COMPANY Helping People Solve Analytical Challenges®

PO Box 329 · Chestertown · Maryland · 21620 · USA

800-344-3100 · 410-778-3100 [Outside U.S.A.] · Fax 410-778-6394 · Visit us on the web at www.lamotte.com