


Insta-TEST®

25 Test Strips
25 Languettes d'analyse
25 Tiras de análisis

- BORATE
- BORATE
- BORATO

LaMotte
Just DIP & READ!



Immerse strip for **5 seconds**. Remove with pad face up. Do NOT Wipe. EXCESS WATER. Wait **15 seconds** and compare to color chart. Keep wet fingers out of the bottle. Close cap tightly after removing strip. In pools or spas, immerse strip (1.5 cm) for best results read in natural daylight. Store in a cool, dry place.

Plongez la bande dans l'eau pendant **5 secondes**. Sortez-la de manière à ce que le capot resté en haut. NE PAS SECOTER. Attendez **15 secondes** et comparez avec la carte de couleurs. Maintenez les doigts humides hors de la bouteille. Bien refermer le bouchon après avoir retiré la bande réactive. Pour les piscines et les spas, plonger la bande à une profondeur de 1,5 cm. Pour un meilleur résultat, réalisez la lecture à la lumière naturelle. Conserver dans un endroit frais et sec.

Sumergir la tira durante **5 segundos**. Saqueala de modo que la almonadilla quede hacia arriba. NO SEQUE. ESPERA **15 segundos** Y compárala con la carta de color. Mantenga los dedos húmedos fuera de la botella. Cierre bien el tapón después de sacar la tira reactiva. En piscinas o spas, sumerja la tira a una profundidad de 1,5 cm (1/2"). Para un mejor resultado, realice la lectura con luz natural. Conserve en un lugar fresco y seco.

LaMotte Co., Chestertown, MD 21620 USA • www.lamotte.com/insta



6 37395 44596 5

Drop holding box and dotted tolerance line